

INSTALLATION INSTRUCTIONS

TGH.0012

PRE-INSTALLATION INSTRUCTIONS

Read this instruction carefully before starting installation. Proper tools will improve the quality of installation and reduce the time if missing parts or any damage found, please take a picture and contact us. Professional installation would be highly recommended. Periodic check to ensure all mounting hardware remains secure and tight. required.

CONTENTS



Loading components

				
Hex Bolts 34	Ram Tools 1	Flat Washer 34	Flange Hex Lock Nuts x20	Ram 16

INSTALLATION INSTRUCTIONS

STEP.1 pre-installation

1.Install the front part first.According to the fender flare's bolt holes,thendrill the 8 bolt holes. The figure shows the bolt holes which needed.



STEP.2 Bracket & Car Mount

Torque the front fenders withhexagonal flat washers andflange nuts.



STEP.1 pre-installation

1.Repeat from step 1



INSTALLATION INSTRUCTIONS

STEP.3 Bracket and pedal mounting



Prepare your own set 13mm wrench & 13mm socket wrench.

STEP.4

Torque the front fenders with hexagonal flat washers and flange nuts.



Wiring Harness installation

Installation: Find the factory fender flares light wiring harness. Connect the wiring harness as follows. Negative Electrode (Black Wire)- Factory Black Wire Turn Lamp (Red Wire)-Factory white Yellow Wire

Notes: Different models may have different wiring harness colors, but the

