

INSTALLATION INSTRUCTIONS

TGH.4012-S

INSTALLATION TIME

About 30 minutes, 1-2 people may be needed. Installation time may differ according to your mechanical skill level.

(PLEASE VERIFY ALL PARTS ARE PRESENT AND READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION!)

CONTENTS



TOOLS REQUIRED



The product parts in this instruction may differ slightly from the actual product contents but generally does not affect the installation of the product

INSTALLATION INSTRUCTIONS

STEP.1

1 Remove your original rear bumper and receiver hitch.



STEP.2

Pay attention to the 5 install holes on each side.



STEP.1

Place the receiver hitch into the car frame and use original bolts to tighten it up. Do the same operation for the other side.



STEP.4

The installation is complete. We hope you enjoy a wonderful off-road life with this quality Hooke Road product!

